REFERENCE: 1949

REAR LAMP LED DYNAMIC INDICATOR LEFT

WARNINGS FOR THE USER:

- Do not look directly into the light it may cause damage or even loss of vision.
- Install only in specialized workshops
- or professional services.
- Use in open space only.
- Use in accordance to the purpose.


INSTALLATION INSTRUCTIONS:


- It should be used exclusively in accordance
- · Mount exclusively in specialized workshops.
- installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- Do not cut off tinned ends.
- Lamps must be installed only in accordance




www.myKAMAR.com

PHOTO AND TECHNICAL DRAWING:







» 20 pcs/bulk box

» ECE R38

	UNECE Regulation 3 UNECE	R6 Regulation 6 (pproved	ulation 7 UNECE Regulation		R38 UNECE Regulation 38 Approved
WIRE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING - Bulk Box
» 450mm	» tail » stop » indicator » fog » reverse	 » 1,6W » 1,6W » 2,2W » 2,3W » 1,0W 	» 12V/24V	» ECE R3 » ECE R6 » ECE R7 » ECE R10 » ECE R23	» cart. dim: 360x140x87mm » lamp weight: 940g

» 1.9W

» reflector

TECHNICAL SPECIFICATIONS:

» 76 LED

» screws

» Lens: PC

» Housing: PC