

HEAD LAMP VO FH2008 RIGHT

WARNINGS FOR THE USER:

- Do not look directly into the light it may cause damage or even loss of vision.
- Install only in specialized workshops or professional services.
- · Use in open space only.
- Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

- It should be used exclusively in accordance with intended use.
- · Mount exclusively in specialized workshops.
- installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- · Do not cut off tinned ends.
- Lamps must be installed only in accordance





www.myKAMAR.com

PHOTO:















TECHNICAL SPECIFICATIONS:

MATERIAL	LIGHT SOURCE	OEM	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING - BULK BOX
» Lens: PC » Housing: PBT	» bulbs H7 »bulbs P21W » 4xLED	» 21035638	» low-beam light» high beam light» position front» indicator	» 70W » 70W » 1W » 21W	» 12/24V	» ECE R6 » ECE R7 » ECE R112	» cart. dim.: 540x390x240mm » weight: 3350g » 4 pcs/bulk box