

# HEADLIGHT LED + POSITION

#### WARNINGS FOR THE USER:

- Do not look directly into the light it may cause damage or even loss of vision.
- Install only in specialized workshops
- or professional services.
- Use in open space only.
- Use in accordance to the purpose.

### INSTALLATION INSTRUCTIONS:


- It should be used exclusively in accordance with intended use.
- Mount exclusively in specialized workshops.
- The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- Do not cut off tinned ends.
- Lamps must be installed only in accordance with UNECE regulations.




www.myKAMAR.com


## PHOTO AND TECHNICAL DRAWING:











### **TECHNICAL SPECIFICATIONS:**

MATERIAL	LED/LM QUANTITY	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING - BULK BOX
» Lens: PC » Housing: AL	» 24+20+20 LED » 10920 LM	» screw	» 250mm with DT connector	» position » driving light » warning lamp	» 4,5W » 100W » 4,5W	» 12V/24V	» ECE R10 » ECE R65 » ECE R148 » ECE R149	<ul> <li>» cart. dim.:</li> <li>240x220x103mm</li> <li>» weight: 1000g</li> <li>» 6 pcs/bulk box</li> </ul>

**R10** 

R65

R148 UNECE Regulation 148 R149 UNECE Regulation 149

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.